Digital Camera

FinePix2800ZOOM Quickstart

FUJIFILM digital

Thank you for choosing the FinePix2800 ZOOM digital camera. The FinePix2800 ZOOM combines some of today's hottest technology—high quality digital imaging, motion picture video with sound, PC-Cam, voice annotation, and much, much more. Follow these simple instructions to begin taking pictures right away. For more detailed instructions on the advanced features, please refer to the Owner's Manual included in your package.

Camera Controls



Picture Taking

A. Loading the batteries



1. Slide battery cover out and lift to open.
2. Insert batteries correctly as indicated by polarity icons.
3. Close battery cover.

B. Setting up the camera

Refer to Owner's Manual for more detailed instructions



1. Open SmartMedia slot.
2. Push the SmartMedia firmly into the SmartMedia slot as far as it will go.
3. Close the slot.
4. Turn the Power on by pressing the "ON/OFF" Switch.

*Refer to Owner's Manual for date/time Setup

C. Taking a picture



1. Set the Mode switch to "📷". (Then EVF switches ON.)
2. To zoom in on the subject, press "🔭" (Tele). To zoom out, press "▦" (Wide).* Optical zoom focal distance (35mm camera equivalent)
3. Press the shutter button down halfway to adjust the focus. Press the shutter button down fully to take a picture, the camera beeps then takes the picture.

D. Viewing your images



1. Set mode switch to "▶".
2. Use "◀" and "▶" to move forward and back through images.

Images That Can be Viewed on the FinePix2800 ZOOM

You can use this camera to view (excluding some uncompressed data) images recorded on a FinePix2800 ZOOM or images recorded onto a 3.3V SmartMedia using a FUJIFILM FinePix series, MX and DX series digital camera.